



## RF Blocking Cell Phone Safe



Sized and shaped in order to accommodate most cell phones, pager and wireless PDA devices, the safe offers more than - 80 dB isolation in transmission from below 1 MHz to over 100 GHz, covering all radio frequencies in use.

Once placed inside the safe, the wireless device will lose all signal. This bag works with all cellular phone bands and technologies including GSM, CDMA, TDMA, GPRS, WiFi, etc.

As a result, phones inadvertently left on will not interfere with hospital or other sensitive equipment. They cannot be made to ring, vibrate, or be detonated from a distance. Since the phone cannot transmit, it cannot be used as a tool to surreptitiously record a nominally secure meeting or divulge an exact location.

### Isolation:

MAC 7007 fabric attenuation performance: Greater than -117 dB from 89 MHz and higher can be seen on the following graph.

